<u>Saver</u>Systems^{*}

DEFY Wood Brightener

Product Data Sheet

MANUFACTURER:

SaverSystems

Richmond, IN 47374 800-860-6327 Fax: 765-935-4999 www.defywoodstain.com

DESCRIPTION

DEFY Wood Brightener is a liquid concentrate that is mixed with water to brighten and restore the natural beauty of exterior wood. It removes tannin and rust stains and is recommended for use on all species of wood, including redwood. DEFY Wood Brightener will not harm wood fibers, grass, or most plants when used properly.

USES

DEFY Wood Brightener removes dirt, grime, tannin, rust, and fungi stains from horizontal and vertical wood surfaces. DEFY Wood Brightener is recommended for surface preparation prior to initial application of clear finishes and stains. It is used as a neutralizer and brightener for all wood species that have been cleaned with DEFY Wood Cleaner. For best results, use SaverSystems water repellent wood finishes.

Note: DEFY Wood Brightener is not formulated to remove intact paint, stain, or clear finishes and may dull painted and metal surfaces if not quickly rinsed.

ADVANTAGES

- Restores the rich look of new wood
- Won't harm most plants or shrubbery
- Will restore redwood or cedar that has been darkened in the cleaning process to its original color

APPLICATION

Shake DEFY Wood Brightener to thoroughly mix. Dilute one part product to four parts water in a plastic container and mix well. Thoroughly wet surface and ALL surrounding vegetation with water before application. Apply solution to wet wood with a sprayer, brush, or mop. Let the solution stand for 3-5 minutes, keeping applied solution wet with additional solution if necessary.

On vertical surfaces, begin applying the solution at the bottom and work to the top. Application may be repeated if desired.

Rinse the wood and all surrounding vegetation thoroughly by flooding the area with water from a garden hose. Rinse vertical surfaces from the bottom up in order to avoid streaking.

Coverage: Each gallon of diluted brightener covers 100-200 sq. ft. depending on wood texture and porosity.

CLEAN UP

Clean tools and equipment immediately after each use with soap and water.

CAUTIONS

Keep out of reach of children. Do not take internally. Avoid contact with eyes and skin. Avoid breathing mist. Close container tightly after each use. Do not re-use containers.

Store only in original container. The use of chemical splash goggles and rubber gloves is recommended when handling this product. Accumulation of product on ladders, scaffolding, decks, etc. may result in a slippery surface.

Contains oxalic acid. Do not mix DEFY Wood Brightener with DEFY Wood Cleaner, chlorine bleach, or other chemicals.

FIRST AID

If inhaled: Ensure fresh air breathing. Allow the victim to rest. In case of breathing difficulties, administer oxygen. Seek medical attention immediately.

If swallowed: Rinse mouth with water (only if the person is conscious). Do NOT induce vomiting unless directed to do so by medical personnel. Immediately call a POISON CENTER or doctor/physician. Obtain emergency medical attention.

For skin contact: Rinse using water. Remove contaminated clothes. Wash skin thoroughly with mild soap and water. If skin irritation persists, seek medical attention.

For eye contact: Immediately flush eyes thoroughly with water for at least 15 minutes. Remove contact lenses, if present and easy to

do. Continue rinsing. Seek medical attention immediately.

For additional information for this product, consult the Safety Data Sheet available at www.defywoodstain.com.

LIMITED WARRANTY

Our recommendations for use of this product are based upon tests believed to be reliable. Since field conditions vary widely, the user must determine the suitability of the product for the particular use and specific method(s) of application. Due to the fact that SaverSystems has no control over surface preparation and application methods, no guarantee as to results is offered, expressed or implied. SaverSystems warrants this product to be free from manufacturing defects.

SaverSystems' liability shall be limited in all events to supplying enough product to re-treat the specific areas to which defective product was applied. This warranty does not include the cost of labor application. SaverSystems shall not have any other liability including direct, incidental, or consequential damages. Some states do not allow the exclusion of incidental or consequential damages, so this limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

PACKAGING

Available in one-gallon recyclable plastic containers.

TRANSPORT AND HANDLING

DEFY Wood Brightener is not considered hazardous under Department of Transportation regulations. Store in cool, dry area. Keep from freezing.

PHYSICAL PROPERTIES

COLOR	Clear to cloudy
ODOR	Slight detergent
SOLVENT	Water
SHELF LIFE2	4 months when unopened